

DRINKWELL® **Hydro-Go!**™

Pet Canteen with Folding Funnel Bowl

Operating Instructions

- 1) The Hydro-Go! Canteen has a capacity of 36 ounces, the flip out bowl will hold 12 ounces of water.
- 2) To fill the Hydro-Go! unscrew the cap. The cap will unscrew counter clockwise. The Hydro-Go! features an extra wide spout for quick filling and is large enough to add ice cubes to keep the water cool on a hot day.

- 3) Once the canteen is filled with water, replace the screw-on cap. The cap will align itself with the indent in the fold-out bowl. (See Fig.1)




Fig. 1

- 4) The Hydro-Go! features a wide nylon shoulder strap for easy carrying. The swivel-clips also help prevent the strap from becoming twisted. You can also convert the shoulder strap into a waist strap by unhooking one of the rotating side clips and shortening the nylon strap to fit your waist. Once you have adjusted the strap, then reconnect the clip. (See Fig. 2)



Fig. 2

5) Using the Hydro-Go!:

- a. Remove the strap from your shoulder or waist. Unhook the hinging bowl by gently lifting up on the clip at the bottom of the canteen bowl. The water bowl will rotate on its hinges to align with the canteen spout. Place the Hydro-Go! on the ground. Alternatively you can also hold the Hydro-Go! for your pet to drink from. (See Fig. 3 & 4)



Fig. 3



Fig. 4

- b. Once the canteen is inline with the bowl, remove the plug and allow water to flow into the bowl. Once the bowl is filled to a desired level, replace the plug in the cap to stop the flow of water. Then allow your pet to drink their fill of water from the bowl. (See Fig. 5)



Fig. 5

- c. Should your pet not drink any or all of the water poured for them, you can easily return the water to the canteen. To do so:
 - i. Remove the plug in the cap then lift the far end of the bowl (where the clip is) slightly higher than the canteen. Apply a small amount of force to keep the bowl and the canteen as close together as possible and pour slowly. Allow the unused water to return to the canteen. A small amount of water loss should be expected. Replace the plug in the cap. Fold the bowl closed until it locks into place with a click. (See Fig. 6)



Fig. 6

- 6) Using the TWO bowl feature of the Hydro-Go!:
- a. When camping or on long hikes, or for use in the RV or car, the Hydro-Go! can be used as both a food and a water bowl. To do this:
 - i. Unhook the clip at the bottom of the bowl and allow the bowl to rotate up 90 degrees. Once the bowl is perpendicular to the canteen, remove the bowl by disconnecting the hinges, lifting on one side of the bowl at a time. Once the water bowl is removed, fill as desired and use the canteen as a separate food bowl. (See Fig. 7 & 8)



Fig. 7



Fig. 8

- b. To reconnect the bowl, hold the bowl at a 90 degree angle to the canteen. Align the hinges with the canteen and gently push down on the hinges to snap them into place. Return the bowl to its resting position and snap into place.
- 7) A dual feature of the Hydro-Go!'s removable bowl is to allow both you and your animal to have a drink. Remove the water bowl as per instruction #6 then fill the water bowl as normal for your animal. Then you are free to drink from the remaining clean water in the canteen. Once both you and your animal are finished with the water, simply replace the plugging cap and snap the bowl back into place per instruction 6b above.
- 8) The Hydro-Go! is dishwasher safe – TOP RACK ONLY.
- a. To wash, remove the strap and unscrew the cap. Also remove the water bowl from the canteen and place in the top rack of the dishwasher.

DRINKWELL®
Hydro-GO!™

Veterinary Ventures Inc.
P.O. Box 19717
Reno, NV 89511
866-322-2530
www.petfountain.com